

# JV33-260BS

## Supplement for the Basic Operation manual

Thank you very much for your purchase of the JV33-260BS.

From the firmware Ver. 4.00, the function below were added. Please read this manual and fully understand it before using the device.

If you have any question, contact your local distributor.

### Perform setting to reduce stripes between passes

In case that feeding stripes cannot be resolved even though media correction is performed, make "MAPS (Mimaki Advanced Pass System) valid. Feeding stripes become less visible by distributing the pass boundary.



- MAPS effect differs depending on the set value of the printing speed. Use it after checking effect in advance.
- When you speed up the printing speed, it takes shorter time to print. However, MAPS effect becomes weak.
- When you slow down the printing speed, it takes longer time to print. However, MAPS effect becomes strong and feeding stripes become less visible.
- The resolutions and passes for which MAPS is enabled are shown in the following table.
- For conditions when MAPS is disabled, the printer operates with MAPS-OFF and print speed settings disabled ( $\pm 0\%$ ).
- MAPS may not be effective depending on image to be printed.
- Slight color change may be found.

Resolution (dpi)	Pass			Resolution (dpi)	Pass		
	4 colors				4 colors		
	$\Delta$	$\circ$	$\odot$		$\Delta$	$\circ$	$\odot$
540x720	2	4	8, 16	720x1080	—	6	12, 24
540x1080	—	6	12, 24	720x1440	—	8	16, 32
720x720	—	4	8, 16				

$\odot$  : MAPS can be used when the print speed setting is within a range of  $\pm 50\%$ , for both high speed and standard speed.

$\circ$  : At high speed, print speed is within the range of  $-50\%$  to  $-1\%$ . At standard speed, MAPS can be used when the print speed is within a range of  $\pm 50\%$ .

$\Delta$  : MAPS can be used when the print speed setting is within the range of  $-50\%$  to  $-1\%$  at standard speed only.

1

Press the **FUNCTION** key in LOCAL.

```
FUNCTION
SETUP                <ENT>
```

2

Press the **ENTER** key.

```
SETUP
SELECT                : TYPE . 1
```

3

Press the **ENTER** key.

```
[ 1 ]
MEDIA COMP.          <ent>
```

4

Press **▲** **▼** to select [MAPS].

```
[ 1 ]
MAPS                  <ent>
```

**5**Press the **ENTER** key.[ 1 ] MAPS  
SETUP : OFF**6**Press **▲** **▼** to set ON/OFF.

• Set Value : OFF, ON

[ 1 ] MAPS  
SETUP : ON**7**Press the **ENTER** key.

• When you select OFF, proceed to the Step 9.

[ 1 ] MAPS  
PRINT SPEED : 0%**8**Press **▲** **▼** to change print speed.

• Set Value : -50 ~ +50%

(If +20% is entered, the print speed increases by approximately 20%. If -20% is entered, the print speed decreases by approximately 20%.)

[ 1 ] MAPS  
PRINT SPEED : 10%**9**Press the **ENTER** key.[ 1 ]  
MAPS <ent >**10**Press the **END** key several times to end the setting.

## Changed contents common to all machine types

### Stop timer setting of deodorize fan/ drier fan

In the machine setting, we changed stop timer setting of deodorize fan/ drier fan from setting by 10 min. to by 1 min. The range of 0 to 240 has not been changed.

	Item	Set value	Outline
Machine Setup	DEODORIZE FAN	STOP TIME	0 ~ <u>120</u> ~ 240min/ CONTINUE
		RENEW	ON / <u>OFF</u>
			Setting the time until the rotation of the exhaust fan is interrupted after the completion of printing.
			Switching the current operation of the exhaust fan.

### Cleaning intervals setting when AUTO CLEANING/ Print CLEANING is "ON"

In the user type setting, we changed max. value of cleaning intervals setting range when AUTO CLEANING/ Print CLEANING is "ON" from 10000mm to 30000mm. The default value (1000mm) has not been changed. Recommended maximum value is 10000mm. In case of setting cleaning intervals beyond 10000mm, nozzle missing may occur depending on the usage environment. Please be careful.

Function name		Set value	Outline
AUTO CLEANING	ON	INTERVAL	10 ~ <u>1000</u> ~ 30000 mm
		TYPE	<u>NORMAL</u> / SOFT / HARD
	OFF		
Print. CLEANING	ON	INTERVAL	10 ~ <u>1000</u> ~ 30000 mm
		TYPE	<u>NORMAL</u> / SOFT / HARD
	OFF		
			Sets the auto cleaning of the print head every completion of printing.
			Sets the auto cleaning of the print head in printing.